



General Notes:

1. Sawcut and remove, along entire length of new curb, 21" +/- 1" from toe of curb, to depth of curb.
2. Place and compact #304 gravel to appropriate depth.
3. Tack curb and existing asphalt faces. Tack gutter if it is to be overlaid.
4. Use vibratory plate compactor to place #448 asphalt in two 2" lifts, matching existing grade.